

INSTRUCTIONS OF USE

After washing, insert the still wet cutlery in the Nicem drying machine.

At the end the cycle, about 30 - 35 seconds later, the cutlery will come out perfectly dry and polished.

