WOODART

Porcelain: EDRG33OB
Cutlery: Anna

EN

The **Woodart** range is available in six natural colours: Beech Grey, Moss Green, Timber Brown, Oak Brown, Walnut Brown and Cedar Orange. These plates radiate a calming and gentle atmosphere, recalling the warmth and structure of wood.

DE

Die **Woodart**-Reihe gibt es in den sechs Naturfarbtönen Beech Grey, Moss Green, Timber Brown, Oak Brown, Walnut Brown und Cedar Orange. Diese Teller strahlen eine angenehme und gelassene Stimmung aus und erinnern stark an die Wärme und Textur von Holz.

FR

La ligne **Woodart** se décline en six coloris naturels Beech Grey, Moss Green, Timber Brown, Oak Brown, Walnut Brown et Cedar Orange. De ces assiettes émane une atmosphère sereine et douce rappelant la chaleur et la structure du bois.

ES

La línea **Woodart** se presenta en seis colores naturales: Beech Grey, Moss Green, Timber Brown, Oak Brown, Walnut Brown y Cedar Orange. De sus platos emana un ambiente sereno y dulce que evoca el calor y la estructura del bosque.

IT

La linea **Woodart** è disponibile in sei colori naturali Beech Grey, Moss Green, Timber Brown, Oak Brown, Walnut Brown e Cedar Orange. Questi piatti emanano un'atmosfera serena e delicata che ricorda il calore e la struttura del legno.

WOODART

FLAT COUPE PLATE

Teller flach coup - Assiette coupe plate - Plato llano coupe - Piatto piano senza falda

5 YEARS ANTI-CHIP GUARANTEE

Ø 29.3 cm / Ht. 3 cm Ø 11 1/2'' / Ht. 1 1/6''	12	WDNNPR29BG WDNNPR29MG WDNNPR29TB WDNNPR29OB WDNNPR29WB WDNNPR29CO
Ø 26.7 cm / Ht. 2.7 cm Ø 10 1/2'' / Ht. 1''	12	WDNNPR27BG WDNNPR27MG WDNNPR27TB WDNNPR27OB WDNNPR27WB WDNNPR27CO
Ø 24 cm / Ht. 2.4 cm Ø 9 4/9'' / Ht. 1''	12	WDNNPR24BG WDNNPR24MG WDNNPR24TB WDNNPR24OB WDNNPR24WB WDNNPR24CO
Ø 20.9 cm / Ht. 2.4 cm Ø 8 2/9'' / Ht. 1''	12	WDNNPR21BG WDNNPR21MG WDNNPR21TB WDNNPR21OB WDNNPR21WB WDNNPR21CO
Ø 15 cm / Ht. 1.9 cm Ø 6'' / Ht. 3/4''	24	WDNNPR15BG WDNNPR15MG WDNNPR15TB WDNNPR15OB WDNNPR15WB WDNNPR15CO

WOODART

DEEP COUPE PLATE
Teller tief coup - Assiette creuse coupe - Plato hondo coupe - Piatto fondo senza falda

5 YEARS ANTI-CHIP GUARANTEE

Ø 25.9 cm / Ht. 4.7 cm / Cont. 120 cl Ø 10 1/5'' / Ht. 1 6/7'' / Cont. 40 4/7 oz	12	WDBUBC26BG WDBUBC26MG WDBUBC26TB WDBUBC26OB WDBUBC26WB WDBUBC26CO
Ø 22.2 cm / Ht. 4 cm / Cont. 70 cl Ø 8 3/4'' / Ht. 1 4/7'' / Cont. 23 2/3 oz	12	WDNNDP23BG WDNNDP23MG WDNNDP23TB WDNNDP23OB WDNNDP23WB WDNNDP23CO

SQUARE PLATE
Teller quadratisch - Assiette carrée - Plato cuadrado - Piatto quadrato

L 30.5 cm / W 30.5 cm / Ht. 1.9 cm L 12'' / W 12'' / Ht. 3/4'' L 28.9 cm / W 28.9 cm L 11 3/8'' / W 11 3/8''	6	WDEDSQ30BG WDEDSQ30MG WDEDSQ30TB WDEDSQ30OB WDEDSQ30WB WDEDSQ30CO

RECTANGULAR SERVING PLATE
Servierteller rechteckig - Assiette à servir rectangulaire - Plato para servir rectangular - Piatto da portata rettangolare

L 33.8 cm / W 18.3 cm / Ht. 2.4 cm L 13 1/3'' / W 7 1/5'' / Ht. 1'' L 32.5 cm / W 17.5 cm L 12 4/5'' / W 6 8/9''	6	WDEDRG33BG WDEDRG33MG WDEDRG33TB WDEDRG33OB WDEDRG33WB WDEDRG33CO

RICE BOWL
Reisschale - Bol à riz - Bol arroz - Coppetta per riso

5 YEARS ANTI-CHIP GUARANTEE

Ø 16 cm / Ht. 6.5 cm / Cont. 58 cl Ø 6 2/7'' / Ht. 2 5/9'' / Cont. 19 3/5 oz	12	WDNNRB16BG WDNNRB16MG WDNNRB16TB WDNNRB16OB WDNNRB16WB WDNNRB16CO

WOODART

NON STACKABLE BOWL

Schale nicht stapelbar - Bol non empilable - Bol no apilable - Coppetta non impilabile

5 YEARS ANTI-CHIP GUARANTEE

Ø 12 cm / Ht. 5.5 cm / Cont. 27 cl Ø 4 5/7'' / Ht. 2 1/6'' / Cont. 9 1/8 oz	12	WDNNBW12BG WDNNBW12MG WDNNBW12TB WDNNBW12OB WDNNBW12WB WDNNBW12CO
Ø 10.5 cm / Ht. 4.5 cm / Cont. 16 cl Ø 4 1/7'' / Ht. 1 7/9'' / Cont. 5 2/5 oz	12	WDNNBW10BG WDNNBW10MG WDNNBW10TB WDNNBW10OB WDNNBW10WB WDNNBW10CO
Ø 9 cm / Ht. 4 cm / Cont. 11 cl Ø 3 1/2'' / Ht. 1 4/7'' / Cont. 3 5/7 oz	12	WDNNBW09BG WDNNBW09MG WDNNBW09TB WDNNBW09OB WDNNBW09WB WDNNBW09CO

CEREAL BOWL

Muesli-Schale - Bol à céréales - Bol a cereales - Coppetta per cereali

5 YEARS ANTI-CHIP GUARANTEE

Ø 20.2 cm / Ht. 8.1 cm / Cont. 130 cl Ø 8'' / Ht. 3 1/5'' / Cont. 44 oz	6	WDNNBW20BG WDNNBW20MG WDNNBW20TB WDNNBW20OB WDNNBW20WB WDNNBW20CO

WOODART

COFFEE CUP
Kaffeetasse - Tasse à café - Taza a café - Tazza da caffè

Ø 9 cm / Ht. 8.3 cm / Cont. 28 cl
Ø 3 1/2'' / Ht. 3 1/4'' / Cont. 9 1/2 oz

WDCLSA17**

12

WDCLCU28BG
WDCLCU28MG
WDCLCU28TB
WDCLCU28OB
WDCLCU28WB
WDCLCU28CO

Ø 8.5 cm / Ht. 7.5 cm / Cont. 23 cl
Ø 3 1/3'' / Ht. 3'' / Cont. 7 7/9 oz

WDCLSA15**

12

WDCLCU23BG
WDCLCU23MG
WDCLCU23TB
WDCLCU23OB
WDCLCU23WB
WDCLCU23CO

Ø 8.4 cm / Ht. 7.2 cm / Cont. 20 cl
Ø 3 1/3'' / Ht. 2 5/6'' / Cont. 6 3/4 oz

WDCLSA15**

12

WDCLCU20BG
WDCLCU20MG
WDCLCU20TB
WDCLCU20OB
WDCLCU20WB
WDCLCU20CO

ESPRESSO CUP
Espressotasse - Tasse à expresso - Taza a expreso - Tazza da espresso

Ø 6.5 cm / Ht. 6.5 cm / Cont. 9 cl
Ø 2 5/9'' / Ht. 2 5/9'' / Cont. 3 oz

WDCLS13**

12

WDCLCU09BG
WDCLCU09MG
WDCLCU09TB
WDCLCU09OB
WDCLCU09WB
WDCLCU09CO

WOODART

SAUCER
Untere - Soucoupe - Platillo - Piattino

Ø 17 cm / Ht. 2 cm Ø 6 2/3'' / Ht. 4/5'' WDCLCU28**	12	WDCLSA17BG WDCLSA17MG WDCLSA17TB WDCLSA17OB WDCLSA17WB WDCLSA17CO
Ø 15 cm / Ht. 1.7 cm Ø 6'' / Ht. 2/3'' WDCLCU23** / WDCLCU20**	12	WDCLSA15BG WDCLSA15MG WDCLSA15TB WDCLSA15OB WDCLSA15WB WDCLSA15CO
Ø 12.5 cm / Ht. 2 cm Ø 5'' / Ht. 4/5'' WDCLCU09**	12	WDCLSA13BG WDCLSA13MG WDCLSA13TB WDCLSA13OB WDCLSA13WB WDCLSA13CO

COFFEE POT & LID
Kaffeekanne & Deckel - Cafetière & couvercle - Cafetera & tapa - Caffettiera & coperchio

Ø 8.8 cm / Ht. 13.6 cm / Cont. 35 cl Ø 3 1/2'' / Ht. 5 1/3'' / Cont. 11 5/6 oz	4	WDCLCP35BG WDCLCP35MG WDCLCP35TB WDCLCP35OB WDCLCP35WB WDCLCP35CO

TEAPOT & LID
Teekanne & Deckel - Théière & couvercle - Tetera & tapa - Teiera & coperchio

Ø 11.2 cm / Ht. 10.8 cm / Cont. 40 cl Ø 4 2/5'' / Ht. 4 1/4'' / Cont. 13 1/2 oz	4	WDCLTP40BG WDCLTP40MG WDCLTP40TB WDCLTP40OB WDCLTP40WB WDCLTP40CO

WOODART

CREAMER
Milchkännchen - Crémier - Lechera - Bricco da latte

Ø 6.8 cm / Ht. 7 cm / Cont. 15 cl
Ø 2 2/3'' / Ht. 2 3/4'' / Cont. 5 oz

12

WDCLCR15BG
WDCLCR15MG
WDCLCR15TB
WDCLCR15OB
WDCLCR15WB
WDCLCR15CO

Beech grey
Moss green
Timber brown
Oak brown
Walnut brown
Cedar orange